



VINTAGE NUT PLATES



Replaceable Nut Information



These are great! If you damage the threads, all you have to do is squeeze the retaining spring with needle nose pliers, remove the damaged nut insert, and replace it with a new insert. These Self Locking Nut Plates, floating, variable counter bore, with replacement nut element; come in both 450 DEG F and 800 DEG F types and are available in 2 lug and 1 lug configuration.

****Disclaimer:** All items sold are in original new surplus condition. This is a collection from surplus aircraft parts inventories gathered over 45 years. Items sold are without certs or traceability and there is no warranty or guarantee expressed or implied.